



TalaSleep Assembly and Operation

Congratulations on your purchase of a new SleepPros Talalay Latex sleep system. Your new SleepPros Talalay Latex sleep system will provide you with years of reliable use and comfortable slumber. If for any reason you have a warranty issue with your new SleepPros Talalay Latex sleep system, please refer to the separate warranty information included. Below are instructions for setting up your new SleepPros Talalay Latex sleep system.

Shipping Contents

- Three 1.9 inch base layers
- One 1.9 inch comfort layer
- One 0.9 inch comfort layer
- One zippered specialty cover

Step-by-step Assembly

- 1) Determine where you want to place your bed. Remove the zippered cover from the box and place it on your foundation. Unzip the cover.
- 2) With the mattress cover unzipped and neatly in place on the foundation, place the bottom of the three base layers in the bottom of the cover. Manipulate the base layer until it is square and centered in the bottom of the cover.
- 3) Place the second of the base layers on top of the first. Manipulate the second layer so the edges and corners line up with the bottom layer. A small flick of the wrist (like flicking a sheet) helps with manipulating the latex layers.
- 4) Place the third of the base layers on top of the second. Manipulate the third layer so the edges and corners line up with the second layer.
- 5) Place the 1.9 inch comfort layer on top of the third base layer. Manipulate the 1.9 inch comfort layer so the edges and corners line up with the third base layer.
- 6) Place the 0.9 inch comfort layer on top of the 1.9 inch comfort layer. Manipulate the 0.9 inch comfort layer so the edges and corners line up with the 1.9 inch comfort layer.
- 7) Zip the cover closed.

That's all there is to it! Easy as pie (or more exactly, easy as a layer cake!) Once assembled, you'll find that because of the friction between layers, the bed will stay square and true. To move the mattress, simply unzip the cover, disassemble, and reassemble in its new location. The firmness level of the mattress can be changed at any time by exchanging the top two comfort layers with firmer or softer pieces of latex.